

2-2. HOW TO DISMANTLE THE KEYBOARD (Refer to Fig. 2-2 and Fig. 2-3)

- 1) Remove 6 screws on the Bottom plate, and disconnect the connectors P1 and P2 on the CPU PC Board.




Fig. 2-2

2-3. HOW TO DISMANTLE THE BEND PANEL BLOCK (Refer to Fig. 2-2 and Fig. 2-3)

- 1) Remove 6 screws as shown Fig. 2-2 and Fig. 2-3, and disconnect the connectors P4, P5 on the CPU PC Board and P1 on the OPERATION (B) PC Board.




Fig. 2-3