

1. PC BOARD BLOCK

REF. NO.	PART NO.	DESCRIPTION
1-1	BA-L1012A030A	PC VOICE BLK AX60
1-2	BA-L1012A040A	PC CPU BLK AX60
1-3	BA-L1012A080A	PC CHORUS BLK AX60
1-4	BA-L1012A060A	PC OPERATION (A) BLK AX60
1-5	BA-L1012A070A	PC OPERATION (B) BLK AX60
1-6	BA-L1012A050A	PC POWER BLK AX60

2. VOICE PC BOARD

REF. NO.	PART NO.	DESCRIPTION
2-IC1, 2	EI-364319	IC CD4051BE
2-IC3, 4	EI-302233	IC TC4051BP
2-IC5 to 20	EI-364245	IC LA6082S
2-IC21 to 27, 41	EI-355113	IC BA715 STD
2-IC28 to 30	EI-310036	IC TC4066BP
2-IC31 to 36	EI-364246	IC CEM3394
2-IC37 to 39	EI-355113	IC BA715 STD
2-IC40	EI-360954	IC IR9311
2-IC42, 43	EI-364247	IC NJM13600
2-IC44, 45	EI-364378	IC LA6082D
2-TR1 to 3	ET-349592	TR 2SC3400 F05
2-TR4	EI-360067	TR 2SC3330 T, U F05
2-TR5, 14, 15	ET-349081	TR 2SC3383 S, T
2-D1	ED-331626	D ZENER H HZ3 B2
2-D2	ED-346463	D ZENER H HZ27FA F10 C3
2-D3	ED-301911	D SILICON H DS448
2-D4 to 19	ED-344280	D SILICON H GMA-01 FY2 F05
2-VR7, 8	EV-336770	R S-FIX H RH0651CS4 3P 0.05W 473
2-R112 to 117	ER-309827	R MF V 1/4W 2703F
2-C80 to 85	EC-362220	C PP V F05 PP 202J 50DC
2-J1	EJ-360771	DIN J TCS5037-01-241 13P
2-1	EJ-363001	SOCKET IC DILB20P-8J

3. CPU PC BOARD

REF. NO.	PART NO.	DESCRIPTION
CPU PC BOARD		
3-IC1	EI-357060	IC UPD7811G-144
3-IC2	EI-355917	IC M74LS373P
3-IC3	EI-354232	IC UPD8279C-2
3-IC4	EI-354149	IC UPD8255AC-2
3-IC5	EI-364250	IC MD6205
3-IC6	EI-364273	IC LF356N
3-IC8, 9	EI-362710	IC LC3517NL-20
3-IC10	EI-354146	IC UPD8253C-2
3-IC11	EI-355917	IC M74LS373P
3-IC12, 15	EI-356049	IC TC74HC139P
3-IC13	EI-355906	IC M74LS14P
3-IC14	EI-360036	IC TC74HC32P
3-IC16	EI-364253	IC PST520D-2
3-IC17	EI-360025	IC TC74HC138P
3-IC18	EI-360954	IC IR9311
3-IC19	EI-364275	IC M74LS05N
3-IC20	EI-355904	IC M74LS04P
3-TR1	ET-349592	TR 2SC3400 F05
3-TR2, 3	ET-349608	TR 2SC3383 T, U
3-TR4	ET-360067	TR 2SC3330 T, U F05
3-D1 to 9	ED-301911	D SILICON H DS448
3-SW1	ES-364255	SW SLIDE SSP322
3-VR1	EV-307709	R S-FIX H PH0651CJ4 3P 0.05W 223
3-PH1	ET-364560	PHOTO SENSOR NJL5127D
3-X1	EI-364257	OSC X'TAL NR-18 12MC
3-CR1, 2	EH-355561	COMP R EXB-R88 103K
3-R30	ER-307764	R MF H F10 1/4W 2211F
3-R31	ER-326169	R FUSE ERD2FC S10 1/4W 22ROG
3-R56	ER-355564	R OMF H S15 FS 1W 911J
3-J1 to 4	EJ-364322	PHONE J 2P HLJ0520-110 W/NUT WASHER
3-J5	EJ-364256	DIN J M1704 3P

REF. NO.	PART NO.	DESCRIPTION
3-1	EJ-358691	SOCKET IC DILB28P-8J
ASSEMBLY BLOCK		
3-IC7	EI-364674	IC TMM2764ADC AX60 V1.2
3-BT1	EZ-358816	BATTERY LITHIUM BR2032-1HF

4. CHORUS PC BOARD

REF. NO.	PART NO.	DESCRIPTION
4-IC1 to 3, 6, 7, 10, 11, 13	EI-337228	IC M5218L
4-IC4, 8	EI-364308	IC MN3009
4-IC5, 9	EI-360228	IC MN3101
4-IC12	EI-353227	IC M5216L
4-TR1, 2, 5, 8, 18	ET-348302	TR FET 2SK381 C, D F05
4-TR3, 4, 12, 13, 16, 17	ET-360067	TR 2SC3330 T, U F05
4-TR6, 7, 11, 15	ET-353899	TR-2SA1317 S, T, U
4-TR9, 10, 14	ET-352994	TR 2SC3401 F05
4-D1 to 10	ED-301911	D SILICON H DS448
4-VR1, 2	EV-358829	R S-FIX H RH0615CJ4J 3P 223
4-VR3	EV-364321	VR ROTARY 12P10x0D B103
4-RL1	EQ-348929	RELAY SIG G5A-232P 2TR 12V
4-R120 to 123	ER-364336	R OMF H S12 FS 1W 201J
4-C9	EC-355170	C PP V S05 CQMFS92 181J 50DC
4-C24	EC-360719	C PP V S05 CQMFS92 101J 50DC
4-C35, 37	EC-364306	C PP V S05 CQMFS92 221J 50DC
4-J3	EJ-353031	PHONE J 3P HLJ0520-010

5. OPERATION (A) PC BOARD

REF. NO.	PART NO.	DESCRIPTION
5-IC1, 2	EI-302233	IC TC4051BP
5-IC3, 4	EI-355909	IC M74LS38P
5-IC5	EI-355910	IC M74LS42P
5-TR1, 2, 3	ET-353899	TR 2SA1317 S, T, U
5-D1 to 4, 7	ED-364261	D LED SLP-981C-50
5-D5, 6	ED-359863	D LED LN81CV-(LF) AK ORANGE
5-SW1 to 22	ES-349367	SW TACT SKHHAK003A
5-VR1 to 14	EV-364267	VR SLIDE 45P1SVOK B103
5-LN1	EM-364260	IND LE GL-7P201

6. OPERATION (B) PC BOARD

REF. NO.	PART NO.	DESCRIPTION
6-IC1	EI-302233	IC TC4051BP
6-TR1 to 5	ET-353899	TR 2SA1317 S, T, U
6-D1 to 38	ED-364261	D LED SLP-981C-50
6-SW1 to 21	ES-349367	SW TACT SKHHAK003A
6-VR1 to 4	EV-364267	VR SLIDE 45P1SVOK B103
6-VR6	EV-364277	VR SLIDE 30P1SVOJ 3BM203 C
6-VR7	EV-364276	VR SLIDE 45PSVOI 3B203