

# SECTION 1

## SERVICE MANUAL

### TABLE OF CONTENTS

I.	SPECIFICATIONS .....	4
II.	DISMANTLING OF UNIT .....	5
	1. HOW TO OPEN THE FRONT PANEL.....	5
	2. HOW TO DISMANTLE THE KEYBOARD.....	5
	3. HOW TO DISMANTLE THE BEND PANEL BLOCK .....	5
III.	CONTROLS .....	6
IV.	THE KEYBOARD REACTION-SHIP TO EQUALLY TEMPERED SCALE FREQUENCIES AND MUSICAL-NOTATION .....	7
V.	PRINCIPAL PARTS LOCATION.....	7
VI.	ADJUSTMENT.....	8
	1. BALANCE OF $\pm 6V$ ON THE POWER SUPPLY PC BOARD .....	8
	2. OFF-SET OF FINAL VCA ON THE VOICE PC BOARD .....	8
	3. BALANCE OF BBD OUTPUT ON THE CHORUS PC BOARD .....	9
	4. OFF-SET OF IC6 (LF 356) ON THE CPU PC BOARD.....	9
VII.	PC BOARD TITLES AND IDENTIFICATION NUMBERS .....	10
VIII.	MIDI IMPLEMENTATION CHART.....	10

This Manual is FOR INTERNAL USE ONLY and must not be made available to unauthorized personal. No part of this manual may be reproduced in any form without permission from AKAI-ELECTRIC CO., LTD., Tokyo, Japan.